



Removing the centre vent

Position a weatherstrip tool between the panel and the dashboard on the short side of the vent.

Detach the catches closest to the weatherstrip tool and pry out and detach the vent at the same time.

Disconnect the connector for the hazard warning signal flasher.

Installing the centre vent

Connect the connector for the hazard warning signal flasher.

Press the panel into place.